
Deebach

Firmware Update Manual

1. Introduction.....	2
2. Install the Update Tool.....	2
3. Firmware Update.....	9

1. Introduction

This manual aims to help you get the latest software programs for your keyboards, digital pianos, digital drums and electric organs.

The update process includes two major steps:

1. Install the update tool to your PC.
2. Update your instrument with the tool.

2. Install the Update Tool


2.1 Preparation



- Make sure your PC has the operating system Windows XP, Windows 7 or Windows 10.
- Disengage the anti-virus programs or security software on PC if there is any.
- If you have installed the update tool, you may skip the following steps and go to **Firmware Update**.


2.2 Double click the setup icon.




2.3 Select your language, then click “Next>” to continue.











2.4 Click “Install” to start the installation.







2.5 Click “Next” to install the device driver.








Note: If the device driver is not installed or is not properly installed,
please refer to [«Install the Update Tool driver»](#), install manually the device driver.

2.6 Click “Finish” to complete the installation.



2.7 Installation is finished. You will find the Firmware update icon on the desktop.




3. Firmware Update

3.1 Preparation

- Connect your instrument to a PC with a standard USB cable.

Note: Never connect the PC with more than one instrument for each update process.


- Make sure the power supply is reliable for the update.



3.2 Double click the Firmware update icon on desktop.



- The Firmware Update window will pop up. Make sure you get the message below before proceeding.




Note: If you fail to get the above message, please try again:


- Check the USB connection or try with another USB cable.
- Try with another USB port on PC.
- Double click the update icon to start the process again.

3.3 Open the update file


The pictures blow shows the update progress of a keyboard.

- Open the update file “xxx.DAT”.






- Check the product model and software version. Now the update is ready.



3.4 Enter the Update Mode

Take the keyboard as an example, press and hold **【STORE】 + 【M1】 + 【M3】** together and turn on the power, it will enter the update mode .




For Deebach BlackBox,


press and hold “UPDATE” and turn on the power, it will enter the update mode.

3.5 Click “↓Update” to start.

Note: Do not disconnect the power supply or turn off the instrument during the update!

Note: The progress bar may repeat several times before the update is finished.





3.6 Finish the update.

- Click “OK” to finish the update process if you get the message “**update successful**”.

The update is completed now.



Note:

- Close the update tool and restart your instrument, it will operate with the latest programs.
- If you need to update another instrument, please repeat **step 3.1 - step 3.6**.
- If any error occurs during the update, you may send the error message to our Support for a solution.

- The end –

Deebach

<http://www.deebach.eu/>

E-Mail: info@deebach.eu

+49 (0) 2162 - 353571

Technischer Support

Telefon: +49(0) 15771805131

E-Mail: support@deebach.eu